

# SCV-2586

# Ultra low outgassing™ potting and encapsulating silicone elastomer

# **DESCRIPTION**

- Two-part, red, low specific gravity, RTV silicone
- 1:1 Mix Ratio (Part A: Part B)

Exceeds the ASTM E 595 low outgas specifications outlined in NASA SP-R-0022A and European Space Agency PSS-014-702, with a TML of  $\le$ 0.1% and CVCM of  $\le$ 0.010%

# **APPLICATION**

- For electronic and space applications requiring Ultra Low Outgassing™ and minimal volatile condensables under to avoid condensation in sensitive devices
- Use a bonding, sealing, or potting material in electronic and space applications
- Provides radiation resistance, low thermal conductivity, oxidation stability, thermal stability and good ablative characteristics
- Especially useful to bond solar cells to solar array panels
- For applications requiring a broader operating temperature range

## **PROPERTIES**

Typical Properties	Average Result	Standard	NT-TM
Uncured:			
Appearance, Part A	Red	ASTM D2090	002
Appearance, Part B	White	ASTM D2090	002
Viscosity, Part A	375,000 cP (375,000 mPas)	ASTM D1084, D2196	001
Viscosity, Part B	275,000 cP (275,000 mPas)	ASTM D1084, D2196	001
Work Time	4 hours	-	008
Cured: 30 minutes at 150°C (302°F)			
Specific Gravity	0.74	ASTM D792	003
Durometer, Type A	45	ASTM D2240	006
Tensile Strength	225 psi (1.6 MPa)	ASTM D412	007
Elongation	150%	ASTM D412	007
Lap Shear Strength (primed w/ CF1-135)	175 psi (1.2 MPa)	ASTM D1002	010



Typical Properties	Average Result	Standard	NT-TM
Collected Volatile Condensable Material (CVCM)	0.003%	ASTM E595	072
Total Mass Loss (TML)	0.04%	ASTM E595	072

Properties tested on a lot-to-lot basis. Do not use the properties shown in this technical profile as a basis for preparing specifications. Please <u>contact</u> NuSil Technology for assistance and recommendations in establishing particular specifications.

#### INSTRUCTIONS FOR USE

#### **Mixing**

Thoroughly stir both parts individually prior to mixing, as some separation may occur. Mix Part A and Part B in a 1:1 ratio by weight.

#### Vacuum Degeration

Remove air entrapped during mixing by common vacuum deaeration procedure, observing all applicable safety precautions. Slowly apply full vacuum to a container rated for use and at least four times the volume of the material being deaerated. Hold vacuum until bulk deaeration is complete.

#### **Inhibition Concerns**

Cures in contact with most materials common to electronic assemblies. Exceptions include butyl and chlorinated rubbers, some RTV silicones and unreacted residues of some curing agents. Units being encapsulated, containers and dispensers should be dry, clean, and free of surface contaminants. Cure inhibition can usually be prevented by washing all containers with solvent or volatizing contaminants by heating.

Note: Some bonding application may require the use of a primer. NuSil Technology CF1-135 silicone primer is recommended.

#### Adjustable Cure Schedule

Product cures a wide range of elevated temperatures and cure times to accommodate different production needs. <u>Contact</u> NuSil Technology for details.

# **OPERATING TEMPERATURE**

The operating temperature range of a silicone in any application is dependent on many variables, including but not limited to: temperature, time of exposure, type of atmosphere, exposure of the material's surface to the atmosphere, and mechanical stress. In addition, a material's physical properties will vary at both the high and low end of the operating temperature range. This type of silicone typically remains

Packaging	Warranty
50 Gram Kit 100 Gram Kit 500 Gram Kit	12 Months

flexible at extremely low temperatures and has been known to perform at -120°C (-248°F) as well as resist breakdown at elevated temperatures up to 300°C (572°F). The user is responsible to verify performance of a material in a specific application.

# **ROHS AND REACH COMPLIANCE**

Please <u>contact</u> NuSil Technology's Regulatory Compliance department with any questions or for further assistance.

### **SPECIFICATIONS**

Do not use the properties shown in this technical profile as a basis for preparing specifications. Please <u>contact</u> NuSil Technology for assistance and recommendations in establishing particular specifications.

#### WARRANTY INFORMATION

The warranty period provided by NuSil Technology LLC (hereinafter "NuSil Technology") is 12 months from the date of shipment when stored below 40°C in original unopened containers. Unless NuSil Technology provides a specific written warranty of fitness for a particular use, NuSil Technology's sole warranty is that the product will meet NuSil Technology's then current specification. NuSil Technology specifically disclaims all other expressed or implied warranties, including, but not limited to, warranties of merchantability and fitness for use. The exclusive remedy and NuSil Technology's sole liability for



breach of warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted. NuSil Technology expressly disclaims any liability for incidental or consequential damages.

# WARNINGS ABOUT PRODUCT SAFETY

NuSil Technology believes, to the best of its knowledge, that the information and data contained herein are accurate and reliable. The user is responsible to determine the material's suitability and safety of use. NuSil Technology cannot know each application's specific requirements and hereby notifies the user that it has not tested or determined this material's suitability or safety for use in any application. The user is responsible to adequately test and determine the safety and suitability for their application and NuSil Technology makes no warranty concerning fitness for any use or purpose. NuSil Technology has completed no testing to establish safety of use in any medical application.

NuSil Technology has tested this material only to determine if the product meets the applicable specifications. (Please <u>contact</u> NuSil Technology for assistance and recommendations when establishing specifications.) When considering the use of NuSil Technology products in a particular application, review the latest Material Safety Data Sheet and <u>contact</u> NuSil Technology with any questions about product safety information.

Do not use any chemical in a food, drug, cosmetic, or medical application or process until having determined the safety and legality of the use. The user is responsible to meet the requirements of the U.S. Food and Drug Administration (FDA) and any other regulatory agencies. Before handling any other materials mentioned in the text, the user is advised to obtain available product safety information and take the necessary steps to ensure safety of use.

# PATENT / INTELLECTUAL PROPERTY WARNING

NuSil Technology disclaims any expressed or implied warranty against the infringement of any domestic or international patent/intellectual property right. NuSil Technology does not warrant the use or sale of the products described herein will not infringe the claims of any domestic or international patent/intellectual property right covering the product itself, its use in combination with other products, or its use in the operation of any process.