

# R-2939

## Low viscosity, thermally conductive silicone

### DESCRIPTION

- Two-part, white, thermally conductive, pourable silicone
- Cure may be heat accelerated
- 15:1 Mix Ratio (Part A: Part B)

### APPLICATION

- To provide heat transfer between electrical/electronic components and their heat sinks
- Use to adhere openings in modules and housings where grooves or other configurations require a limited flow material with moderate thermal conductivity

### PROPERTIES

Typical Properties	Average Result	Standard	NT-TM
<b>Uncured:</b>			
Appearance*	White	ASTM D2090	002
Viscosity, Part A*	70,000 cP (70,000 mPas)	ASTM D1084, D2196	001
Work Time*	4 hours	-	008
<b>Cured: 30 minutes at 150°C (302°F)</b>			
Specific Gravity*	1.34	ASTM D792	003
Durometer, Type A*	70	ASTM D2240	006
Tensile Strength*	300 psi (2.1 MPa)	ASTM D412	007
Elongation*	70%	ASTM D412	007
Tear Strength*	45 ppi (7.9 kN/m)	ASTM D624	009
Thermal Conductivity*	0.75 W/(mK) (18 x 10 <sup>-4</sup> cal/(cm·sec·°C))	ASTM E1530	101
Dielectric Strength	810 Volts/mil (31.9 kV/mm)	ASTM D149	-

\*Properties tested on a lot-to-lot basis. Do not use the properties shown in this technical profile as a basis for preparing specifications. Please [contact](#) NuSil Technology for assistance and recommendations in establishing particular specifications and testing parameters.

## INSTRUCTIONS FOR USE

### Mixing

Stir Part A well prior to weighing for mixing to ensure the filler is homogeneous throughout. Thoroughly mix in a ratio of 15:1 Part A to Part B.

### Vacuum Deaeration

Remove air entrapped during mixing by common vacuum deaeration procedure, observing all applicable safety precautions. Slowly apply vacuum to a container rated for use and of volume at least four times that of material being deaerated. Hold vacuum until presence of air is no longer evident.

### Inhibition Concerns

R-2939 will cure in contact with most materials. Exceptions include butyl and chlorinated rubbers, some RTV silicones and unreacted residues of some curing agents.

Note: Some bonding applications may require the use of a primer. NuSil Technology CF1-135 silicone primer is recommended.

### Adjustable Cure Schedule

Product cures at room temperature and a wide range of elevated temperatures and cure times to accommodate different production needs. [Contact](#) NuSil Technology for details.

## OPERATING TEMPERATURE

The operating temperature range of a silicone in any application is dependent on many variables, including but not limited to: temperature, time of exposure, type of atmosphere, exposure of the material's surface to the atmosphere, and mechanical stress. In addition, a material's physical properties will vary at both the high and low end of the operating temperature range. Silicone typically remains flexible at extremely low temperatures and has been known to perform at -50°C (-58°F) as well as resist breakdown at elevated temperatures up to 250°C (482°F). The user is responsible to verify performance of a material in a specific application.

## ROHS AND REACH COMPLIANCE

Please [contact](#) NuSil Technology's Regulatory Compliance department with any questions or for further assistance.

### Packaging

100 Gram Kit  
250 Gram Kit  
500 Gram Kit  
1 Pint Kit (503 g)

### Warranty

12 Months

## SPECIFICATIONS

Do not use the properties shown in this technical profile as a basis for preparing specifications. Please [contact](#) NuSil Technology for assistance and recommendations in establishing particular specifications.

## WARRANTY INFORMATION

The warranty period provided by NuSil Technology LLC (hereinafter "NuSil Technology") is 12 months from the date of shipment when stored below 40°C in original unopened containers. Unless NuSil Technology provides a specific written warranty of fitness for a particular use, NuSil Technology's sole warranty is that the product will meet NuSil Technology's then current specification. NuSil Technology specifically disclaims all other expressed or implied warranties, including, but not limited to, warranties of merchantability and fitness for use. The exclusive remedy and NuSil Technology's sole liability for breach of warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted. NuSil Technology expressly disclaims any liability for incidental or consequential damages.

## WARNINGS ABOUT PRODUCT SAFETY

NuSil Technology believes, to the best of its knowledge, that the information and data contained herein are accurate and reliable. The user is responsible to determine the material's suitability and safety of use. NuSil Technology cannot know each application's specific requirements and hereby notifies the user that it has not tested or determined this material's suitability or safety for use in any application. The user is responsible to adequately test and determine the safety and suitability for their application and NuSil Technology makes no warranty concerning fitness for any use or purpose. NuSil Technology has completed no testing to establish safety of use in any medical application.

NuSil Technology has tested this material only to determine if the product meets the applicable specifications. (Please [contact](#) NuSil Technology for assistance and recommendations when establishing specifications.) When considering the use of NuSil Technology products in a particular application, review the latest Material Safety Data Sheet and [contact](#) NuSil Technology with any questions about product safety information.

Do not use any chemical in a food, drug, cosmetic, or medical application or process until having determined the safety and legality of the use. The user is responsible to meet the requirements of the U.S. Food and Drug Administration (FDA) and any other regulatory agencies. Before handling any other materials mentioned in the text, the user is advised to obtain

available product safety information and take the necessary steps to ensure safety of use.

### **PATENT / INTELLECTUAL PROPERTY WARNING**

NuSil Technology disclaims any expressed or implied warranty against the infringement of any domestic or international patent/intellectual property right. NuSil Technology does not warrant the use or sale of the products described herein will not infringe the claims of any domestic or international patent/intellectual property right covering the product itself, its use in combination with other products, or its use in the operation of any process.